

# Types of Display fridges

How and where to fit fridge covers

# Island fridges

- A) Jumbo island with a “crown end”  
These cases have 2 sides. A 12ft/3.6m case will have 4 x 6ft curtains ie 2 each side of the centre platform. (Crown end shown here)
- B) The “wide island” is show below and each 12ft will take only 2x 6ft covers and a protective rail is recommended to prevent damage to covers



# Upright fridges

- A Hill upright Meat case. Also referred to as a multi deck or 3 tier.
- A Hill upright Dairy case is in the background.
- Two 6ft / 1.8m wide curtains are shown covering 12ft/3.66m



# Curved glass / Deli cases

- A 4ft/1.2m wide curtains is shown on this bakery curved glass display case. The drop is normally 450-600mm from top to bottom.
- A thicker 175micron material is used for these cases where covers are being opened and closed often.



# Low meat

- The covers for low meat cases can be mounted where the dotted line is on the front edge of the display opening.



# Wrap around cases

## A. Open Wrap case.

Covers for these cases normally fit on top as there is normally no space inside the top canopy to fit them



## B. The closed wrap .

has glass sides on the ends as indicated.



# Hi/low upright

- These cases are very similar to the “pyramid” type wrap around cases but don’t have the ends. The openings from top to bottom is normally less than 1,3m.
- Covers need to be fitted on top in most cases as there is normally not enough room inside the top canopy to fit them. The roll or single roll curtains will normally be long enough to cover the opening

